


X9 Manual



1 Control panel



press and hold the power button for 2 seconds to turn on the machine, and the machine enters standby mode, press and hold the button again for 2 seconds The machine is turned off; shortpress the power button, the machine pauses, short press the power button again, the machine continues to run



Indicator light is on after the machine is powered on. When the thrusting speed reaches the maximum, the indicator light flashes quickly. When the penis function reaches the maximum, the indicator light flashes slowly.



short press this key, the speed will increase from 1st gear to 9th gear; long press this button for 2 seconds, the machine will enter the stepless speed regulation mode, the speed will increase from 0 to the maximum, when the speed increases to the speed you want just release the button and the indicator light will flash quickly at the maximum gear.



short press this key, the speed decreases from 9th gear to 1st gear; long press this button for 2 seconds, the machine enters the stepless speed regulation mode, the speed decreases from the maximum to 0; when it increases to the desired speed just release the button.



Short press this button to control the "vibration motor/rotation motor", the speed increases from 1st gear to 6th gear, and the cycle repeats: the indicator light flashes slowly at the maximum gear.


2 Specification

Power: 72W Speed frequency: 0~260strokes/m

Voltage: 100~240V Thrust distance: 60MM

Remote Control Distance: 5M+

3 Machine size



4 Remote control



press and hold the power button for 2 seconds to turn on the machine, and the machine enters standby mode, press and hold the button again for 2 seconds The machine is turned off; shortpress the power button, the machine pauses, short press the power button again, the machine continues to run



Short press the "A" key, and the speed increases from gear 1 to gear 9. Repeat the cycle; long press the "A" key for 2 seconds, the machine enters the stepless speed regulation mode, and the speed increases from 0 to the maximum. When the speed increases to the speed you want, release the button. If you press the "A" key shortly, the stepless speed change will stop and the main motor will turn off; Whenever you press the "A" key for more than 2 seconds, the main motor will enter the stepless speed change mode. The indicator light flashes quickly at the maximum gear.



Short press the "B" button to control the "vibration motor/rotation motor", the speed increases from 1th to 6th gear, repeat the cycle, and the indicator light flashes slowly at the maximum gear.



Short press the "H" key, one key to activate, all motors will output at full capacity, and the indicator lights will flash quickly.

Note: 2pcs AAA batteries are used for the remote control, which need to be prepared by the user


5 Posture



6 Storage box



The large storage box can store power supply, dildos and other accessories



To open or close the storage box lid, it is best to stand the machine upright and place it on a flat surface. Turn the lid counterclockwise with hands to open it. When closing, align the red hook on the lid as shown in the left picture with the red card slot cover as shown in the right picture, and turn the lid clockwise with both hands.

